



B&K Precision Corporation

22820 Savi Ranch Parkway Yorba Linda, CA 92887 U.S.A.

Phone: (714) 921-9095

Fax: (714) 921-6422

Getting Started

Installing security dongle

Before the **CompactLink** software can be used, the USB security dongle must be installed. The drivers are included on the **CompactLink** installation CD and must be installed as follows:

- Ensure you are running Windows on an account with Administrator privileges.
- Insert the CompactLink CD in the CD or DVD drive.
- Click "Start, Run, Browse" on your PC and navigate to your CD ROM drive (usually drive D).
- Select the file "CBUSetup.exe" and click "Open", then click "OK" to start the installation.
- Follow the instruction on the screen.

Once the installation has completed, the USB security token can be inserted into any available USB socket on your computer.

Installing CompactLink

To install the CompactLink software, follow this step by step procedure:

- Insert the CompactLink CD in your CD or DVD drive.
- Click "Start, Run, Browse" on your PC and navigate to your CD ROM drive (usually drive D).
- Select the file "setup.exe" and click "Open", then click "OK" to start the installation.
- Follow the installation instructions on the screen. We recommend that all options are left at their default values.

Running CompactLink

To launch the software, click *Start/Programs/CompactLink/CompactLink* on your PC. You can also create a desktop shortcut if you wish to make starting easier. The opening screen shows the *Review Library* screen displaying a list of devices in the current library and provides a menu to access all software functions.