

1



Remove the CY4672 PRO LP Reference Design Kit bridge dongle, keyboard, and mouse from the package.

2




Connect the bridge dongle to the PC. The bridge enumerates as a human interface device (HID).

3




Power the mouse and keyboard with two AA batteries each.

4



Turn on the mouse. Press the bind button on the bridge; the red LED blinks. Press the bind button on the mouse to bind it with the bridge.

5



Press the bind button on the bridge; the red LED blinks. Press the bind button on the keyboard to bind it with the bridge. The mouse and keyboard work smoothly with the PC.


6




Insert the CY4672 kit CD. Install PSoC Designer and PSoC Programmer.

CY4672 ProC LP Reference Design Kit Details


Bridge Dongle




CYRF69213 Chip



Keyboard



Mouse



For the latest information about this kit, visit
<http://www.cypress.com/go/CY4672>

