
Manual Switches

Covers for Paddle Switches



Colored covers simply snap into the top of paddle switch housings.

COLOR DISPLAY OPTIONS

Transmitted color — Color is displayed whether lamp is On or Off. Choice of 1-piece covers (types 10 or 20) or covers with clear cap and colored translucent insert (types 11 or 12).

Dead front hidden color/hidden legend — Cover appears black with lamp Off. Legend and color appear when illuminated (types 30 or 40).

G

Projected color — Translucent white cover with transparent colored insert (types 50 or 60). White cover appears colored when illuminated.

AML53 PADDLE SWITCH COVER ORDER GUIDE (All possible color combinations may not be available.)

For AML13, AML23, and AML33 incandescent or non-lighted display.



	Т	Ť	
	Cove	Cover Color	
end	1/2 cover, or one side of two-piece cover	Other side of two-piece cover (see note)	
color and on color and on tt cap ert) and on Color and color and and on	R Red Y Yellow G Green B Blue ***W White K* Black L* Gray A** Amber	R Red Y Yellow G Green B Blue ***W White K* Black L* Gray A** Amber	

Note: Only one color code letter is necessary when ordering 1/2 covers.

Example: AML53-T10RG

Two-piece cover; with transmitted color,

no legend; red and green.

*Not for lighted display.

**Not available with projected color.

***Insert is clear for projected color when "W"


AML55 PADDLE SWITCH COVER ORDER GUIDE (All possible color combinations may not be available.)

For AML35 neon display.





R T
Lens Color
T Clear
R Red



AML55-N covers have a colored lenticular lens window which extends over the neon lamp.

Example: AML55-N10RY

Full neon paddle switch cover; with transmitted color, no legend; red lens and yel-

low cover.