

Cables for I/O Relay Terminals

XW2Z-R

Connect I/O Relay Terminals to I/O Units for Programmable Controllers with one touch.

- Cables with Connectors for G70V and G7TC I/O Relay Terminals, G70D and G70R Relay Terminals, and G70A and P7TF-IS/OS I/O Terminal Sockets.
- Cables with loose wires available with or without crimp terminals.
- Cables available for programmable controllers from Mitsubishi Electric.











Cable Types and Table of Contents

Connects to	Appearance	Description	Name	I/O Classification	Typical model	Wiring diagram	
						Page	Number
Connections with terminal blocks of various devices		This Cable is convenient for connecting I/O Relay Terminals to devices equipped with screw terminals.	Cables with Loose Wires and Crimp Terminals	16 I/O points	XW2Z-RY□C	4	(1)
		This Cable has loose wires at the device end.	Cables with Loose Wires	16 I/O points	XW2Z-RA□C		(2)
Fujitsu connectors		Connects a PLC I/O Unit, DeviceNet slave or other device with Fujitsu connectors 1:1 to an I/O Relay Terminal.	Cables with Connectors (1:1)	16 I/O points	XW2Z-R□C	5	(3)
		Connects a PLC I/O Unit, DeviceNet slave, or other device with Fujitsu connectors 1:2 to I/O Relay Terminals.	Cables with Connectors (1:2)	32 input points	XW2Z-RI□C-□		(4)
				32 output points	XW2Z-RO□C-□		(5)
		Connects a PLC I/O Unit, DeviceNet slave, or other device with Fujitsu connectors 1:3 to I/O Relay Terminals.	Cables with Connectors (1:3)	48 I/O points	XW2Z-R□C-□-□	6	(6)
MIL connectors		Connects a PLC I/O Unit, DeviceNet slave, or other device with MIL connectors 1:1 to an I/O Relay Terminal.	Cables with Connectors (1:1)	16 input points/ 16 output points	XW2Z-RO□C	7	(7)
					XW2Z-RI□C		(8)
		Connects a PLC I/O Unit, DeviceNet slave, or other device with MIL connectors 1:2 to I/O Relay Terminals.	Cables with Connectors (1:2)	32 input points/ 32 output points	XW2Z-RO□-□-D1	8	(9)
					XW2Z-RI□-□-D1		(10)
					XW2Z-RI□-□-D2		(11)
		Connects a DeviceNet slave or other device with MIL connectors 1:2 to I/O Relay Terminals.		16 input points/ 16 output points (32 I/O points)	XW2Z-RM□-□-D1	9	(12)
					XW2Z-RM□-□-D2		(13)
Mitsubishi Electric PLCs Applicable models: For inputs: AX42, A1SX41, A1SX42, QX41, and QX42 For outputs: AY42, A1SY41, A1SY42, QY41P, and QY42P		Connects Mitsubishi Electric PLCs with 32-point connectors to I/O Relay Terminals through a special cable.	Mitsubishi Electric PLC Connecting Cables (1:2)	32 input points	XW2Z-RI□C-MN	10	(14)
				32 output points	XW2Z-RO□C-MN		(15)

Note: For combinations of Connections, refer to I/O Relay Terminals and Connected Devices (Cat. No. J217) or to the datasheets for related products.

Ordering Information

Type (A side)	Name	I/O Classification	Appearance	Cable length L (mm)		Models	
Loose wire connections	Cables with Loose Wires and Crimp Terminals XW2Z-RY□C	16 I/O points		1,000		XW2Z-RY100C	
				1,500		XW2Z-RY150C	
				2,000		XW2Z-RY200C	
				3,000		XW2Z-RY300C	
				5,000		XW2Z-RY500C	
	Cables with Loose Wires XW2Z-RA□C	16 I/O points		2,000		XW2Z-RA200C	
5,000					XW2Z-RA500C		
Fujitsu connectors (24 pins)	Cables with Connectors (1:1) XW2Z-R□C	16 I/O points		1,000		XW2Z-R100C	
				1,500		XW2Z-R150C	
				2,000		XW2Z-R200C	
				3,000		XW2Z-R300C	
				5,000		XW2Z-R500C	
Fujitsu connectors (40 pins)	Cables with Connectors (1:2) XW2Z-RI□C-□ XW2Z-RO□C-□	32 input points		(A) 1,000	(B) 750	XW2Z-RI100C-75	
				(A) 1,500	(B) 1,250	XW2Z-RI150C-125	
				(A) 2,000	(B) 1,750	XW2Z-RI200C-175	
				(A) 3,000	(B) 2,750	XW2Z-RI300C-275	
				(A) 5,000	(B) 4,750	XW2Z-RI500C-475	
		32 output points		(A) 1,000	(B) 750	XW2Z-RO100C-75	
				(A) 1,500	(B) 1,250	XW2Z-RO150C-125	
				(A) 2,000	(B) 1,750	XW2Z-RO200C-175	
				(A) 3,000	(B) 2,750	XW2Z-RO300C-275	
				(A) 5,000	(B) 4,750	XW2Z-RO500C-475	
Fujitsu connectors (56 pins)	Cables with Connectors (1:3) XW2Z-R□C-□-□	48 I/O points		(A) 1,500	(B) 1,250	(C) 1,000	XW2Z-R150C-125-100
				(A) 2,000	(B) 1,750	(C) 1,500	XW2Z-R200C-175-150
				(A) 3,000	(B) 2,750	(C) 2,500	XW2Z-R300C-275-250
MIL connectors (20 pins)	Cables with Connectors (1:1) XW2Z-RO□C XW2Z-RI□C	16 I/O points		250			XW2Z-RO25C
				500			XW2Z-RO50C
				250			XW2Z-RI25C
				500			XW2Z-RI50C

Type (A side)	Name	I/O Classification	Appearance	Cable length L (mm)		Models		
MIL connectors (40 pins)	Cables with Connectors (1:2) XW2Z-RO□-□-D1, XW2Z-RI□-□-D1, XW2Z-RI□-□-D2, XW2Z-RM□-□-D1*, XW2Z-RM□-□-D2*	32 I/O points		(A) 500	(B) 250	XW2Z-RO50-25-D1		
				(A) 750	(B) 500	XW2Z-RO75-50-D1		
				(A) 1,000	(B) 750	XW2Z-RO100-75-D1		
				(A) 1,500	(B) 1,250	XW2Z-RO150-125-D1		
				(A) 2,000	(B) 1,750	XW2Z-RO200-175-D1		
				(A) 3,000	(B) 2,750	XW2Z-RO300-275-D1		
				(A) 5,000	(B) 4,750	XW2Z-RO500-475-D1		
				(A) 500	(B) 250	XW2Z-RI50-25-D1		
				(A) 750	(B) 500	XW2Z-RI75-50-D1		
				(A) 1,000	(B) 750	XW2Z-RI100-75-D1		
				(A) 1,500	(B) 1,250	XW2Z-RI150-125-D1		
				(A) 2,000	(B) 1,750	XW2Z-RI200-175-D1		
				(A) 3,000	(B) 2,750	XW2Z-RI300-275-D1		
				(A) 5,000	(B) 4,750	XW2Z-RI500-475-D1		
		16 inputs and 16 outputs (32 I/O points)		(A) 500	(B) 250	XW2Z-RI50-25-D2		
				(A) 750	(B) 500	XW2Z-RI75-50-D2		
				(A) 500	(B) 250	XW2Z-RM50-25-D1		
				(A) 750	(B) 500	XW2Z-RM75-50-D1		
				(A) 1,000	(B) 750	XW2Z-RM100-75-D1		
				(A) 1,500	(B) 1,250	XW2Z-RM150-125-D1		
				(A) 2,000	(B) 1,750	XW2Z-RM200-175-D1		
				(A) 3,000	(B) 2,750	XW2Z-RM300-275-D1		
				(A) 5,000	(B) 4,750	XW2Z-RM500-475-D1		
				(A) 500	(B) 250	XW2Z-RM50-25-D2		
				(A) 750	(B) 500	XW2Z-RM75-50-D2		
Mitsubishi Electric PLCs with 32-point connectors (1:2) Applicable models: For inputs: AX42, A1SX41, A1SX42, QX41, and QX42 For outputs: AY42, A1SY41, A1SY42, QY41P, and QY42P	Mitsubishi Electric PLC Connecting Cables XW2Z-RI□C-□-MN XW2Z-RO□C-□-MN	32 input points		(A) 1,000	(B) 750	XW2Z-RI100C-75-MN		
		32 output points		(A) 1,500	(B) 1,250	XW2Z-RI150C-125-MN		
				(A) 2,000	(B) 1,750	XW2Z-RI200C-175-MN		
				(A) 3,000	(B) 2,750	XW2Z-RI300C-275-MN		
				(A) 1,000	(B) 750	XW2Z-RO100C-75-MN		
				(A) 1,500	(B) 1,250	XW2Z-RO150C-125-MN		
				(A) 2,000	(B) 1,750	XW2Z-RO200C-175-MN		
				(A) 3,000	(B) 2,750	XW2Z-RO300C-275-MN		
						(A) 1,000	(B) 750	XW2Z-RO100C-75-MN
						(A) 1,500	(B) 1,250	XW2Z-RO150C-125-MN
						(A) 2,000	(B) 1,750	XW2Z-RO200C-175-MN
		(A) 3,000	(B) 2,750	XW2Z-RO300C-275-MN				

Note: For a connector pin assignment diagram and cable color information, refer to the wiring drawings.

* These cables are used to connect to slave products for DeviceNet and other networks.

XW2Z-R

Wiring diagram

For various devices


(1) Cables with Loose Wires and Crimp Terminals (16 I/O points)

XW2Z-RY□C

A side				B side	
Marker tube No. *1	Insulation color	Dot mark	Dot color	CN1 Pin No.	Corresponding G70V/G7TC connector pin number*2
20	BLUE	■	RED	1	20
10	BLUE	■	BLACK	2	10
19	PINK	■	RED	3	19
9	PINK	■	BLACK	4	9
18	GREEN	■	RED	5	18
8	GREEN	■	BLACK	6	8
17	ORANGE	■	RED	7	17
7	ORANGE	■	BLACK	8	7
16	GRAY	■	RED	9	16
6	GRAY	■	BLACK	10	6
15	BLUE	■ ■	RED	11	15
5	BLUE	■ ■	BLACK	12	5
14	PINK	■ ■	RED	13	14
4	PINK	■ ■	BLACK	14	4
13	GREEN	■ ■	RED	15	13
3	GREEN	■ ■	BLACK	16	3
12	ORANGE	■ ■	RED	17	12
2	ORANGE	■ ■	BLACK	18	2
11	GRAY	■ ■	RED	19	11
1	GRAY	■ ■	BLACK	20	1

*1. Marker tube numbers and the G70V and G7TC connector pin numbers are same. Be careful when using with other models (Relay Terminals). Refer to the datasheet for specific products for details.

*2. Refer to the datasheets for the G70V and G7TC for the connector pin layouts of I/O Relay Terminals.



Item	Part	
Terminal Connector	A side	Loose Wires and Crimp Terminals (fork terminal (1.25-3))
	B side	XG4M-2030-T (MIL connector)
Cable	UL2464 BC10P-SB AWG28(7/0.127) Interface cable (Cable color: Gray)	


- Note:**
1. The power line capacity is 50 mA max. per I/O point. Also, always check the driver capacity and I/O relay power consumption when using for outputs.
 2. The crimp terminals are labeled with the corresponding connector pin numbers in parentheses. Refer to the Connector Pin No. Tables for marker tube numbers.
 3. Connect terminals 9 and 19 and terminals 10 and 20 together when using the G7TC-OC08.
 4. The wire gauge of the wires in the cable is 28 AWG (7/ 0.127).

(2) Cables with Loose Wires (16 I/O points)


XW2Z-RA□C

A side			B side	
Insulation color	Dot mark	Dot color	CN1 Pin No.	Corresponding G70V/G7TC connector pin number*
ORANGE	■	BLACK	20	1
ORANGE	■	RED	19	11
GRAY	■	BLACK	18	2
GRAY	■	RED	17	12
WHITE	■	BLACK	16	3
WHITE	■	RED	15	13
YELLOW	■	BLACK	14	4
YELLOW	■	RED	13	14
PINK	■	BLACK	12	5
PINK	■	RED	11	15
ORANGE	■ ■	BLACK	10	6
ORANGE	■ ■	RED	9	16
GRAY	■ ■	BLACK	8	7
GRAY	■ ■	RED	7	17
WHITE	■ ■	BLACK	6	8
WHITE	■ ■	RED	5	18
YELLOW	■ ■	BLACK	4	9
YELLOW	■ ■	RED	3	19
PINK	■ ■	BLACK	2	10
PINK	■ ■	RED	1	20

* Refer to the datasheets for the G70V and G7TC for the connector pin layouts of I/O Relay Terminals.



Connector Pin Diagram
(from Connector Mating Side)



Item	Part	
Terminal Connector	A side	Loose Wires
	B side	XG5M-2032-N XG5S-2012 (MIL connector)
Cable	UL2464 BC10P-SB AWG24(7/0.203) Interface cable (Cable color: Black)	


- Note:**
1. The wire gauge of the wires in the cable is 24 AWG (7/0.203).
 2. Connect terminals 9 and 19 and terminals 10 and 20 together when using the G7TC-OC08.

For Fujitsu connectors

(3) Cables with Connectors (1:1) (16 I/O points)

XW2Z-R□C

CN1	CN2
1A	20
1B	19
2A	18
2B	17
3A	16
3B	15
4A	14
4B	13
5A	12
5B	11
6A	10
6B	9
7A	8
7B	7
8A	6
8B	5
9A	4
9B	3
10A	2
10B	1
11A	NC
11B	
12A	
12B	




Item	Part	
Terminal Connector	A side	FCN-367J024-AU/F *
	B side	XG4M-2030-T (MIL connector)
Cable	UL2464 BC10P-SB AWG28(7/0.127) Interface cable (Cable color: Gray)	

* The connector is made by Fujitsu Component Ltd.

(4) Cables with Connectors (1:2) (32 I/O points)

XW2Z-RI□C-□

CN1	CN2	CN3
1A	20	---
1B	---	20
2A	18	---
2B	---	18
3A	16	---
3B	---	16
4A	14	---
4B	---	14
5A	12	---
5B	---	12
6A	10	---
6B	---	10
7A	8	---
7B	---	8
8A	6	---
8B	---	6
9A	4	---
9B	---	4
10A	19	---
10B	---	19
11A	17	---
11B	---	17
12A	15	---
12B	---	15
13A	13	---
13B	---	13
14A	11	---
14B	---	11
15A	9	---
15B	---	9
16A	7	---
16B	---	7
17A	5	---
17B	---	5
18A	3	---
18B	---	3
19A	NC	
19B		
20A		
20B		



Item	Part	
Terminal Connector	A side	FCN-367J040-AU/FW *
	B side	XG4M-2030-T×2 (MIL connector)
Cable	UL2464 BC20P-SB AWG28(7/0.127) Interface cable Cable color: Gray Tube color: XW2Z-RI□C-□ CN2, CN3: Red XW2Z-RO□C-□ CN2, CN3: Yellow	


* The connector is made by Fujitsu Component Ltd.

For Fujitsu connectors


(6) Cables with Connectors (1:3) (48 I/O points)

XW2Z-R□C-□-□

CN1	CN2	CN3	CN4
1A	20	---	---
1B	19	---	---
2A	18	---	---
2B	17	---	---
3A	16	---	---
3B	15	---	---
4A	14	---	---
4B	13	---	---
5A	12	---	---
5B	11	---	---
6A	10	---	---
6B	9	---	---
7A	8	---	---
7B	7	---	---
8A	6	---	---
8B	5	---	---
9A	4	---	---
9B	1	---	---
10A	---	20	---
10B	---	19	---
11A	---	18	---
11B	---	17	---
12A	---	16	---
12B	---	15	---
13A	---	14	---
13B	---	13	---
14A	---	12	---
14B	---	11	---
15A	---	10	---
15B	---	9	---
16A	---	8	---
16B	---	7	---
17A	---	6	---
17B	---	5	---
18A	---	4	---
18B	---	1	---
19A	---	---	20
19B	---	---	19
20A	---	---	18
20B	---	---	17
21A	---	---	16
21B	---	---	15
22A	---	---	14
22B	---	---	13
23A	---	---	12
23B	---	---	11
24A	---	---	10
24B	---	---	9
25A	---	---	8
25B	---	---	7
26A	---	---	6
26B	---	---	5
27A	---	---	4
27B	---	---	1
28A	NC		
28B	NC		



Connector Pin Diagram
(from Connector Mating Side)



Item	Part	
Terminal Connector	A side	FCN-367J056-AU/FW*
	B side	XG4M-2030-T×3 (MIL connector)
Cable	UL2464 BC30P-SB AWG28(7/0.127)	
	Interface cable	
	Cable color: Gray Tube color: CN2, CN3, CN4: Black	

* The connector is made by Fujitsu Component Ltd.

For MIL connectors

(7) Cables with Connectors (1:1) (16 I/O points)


XW2Z-RO□C

CN1	CN2
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16
17	17
18	18
19	19
20	20


(8) Cables with Connectors (1:1) (16 I/O points)

XW2Z-RI□C

CN1	CN2
3	1
4	2
1	3
2	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16
17	17
18	18
19	19
20	20



Connector Pin Diagram
(from Connector Mating Side)



Item	Part	
Terminal Connector	A side	XG4M-2030-T (MIL connector)
	B side	XG4M-2030-T (MIL connector)
Cable	UL2464 BC10P-SB AWG28(7/0.127) Interface cable (Cable color: Gray)	

For MIL connectors

(9) Cables with Connectors (1:2)
(32 I/O points)

XW2Z-RO□-□-D1

CN1	CN2	CN3
1	---	1
2	---	2
3	---	3
4	---	4
5	---	5
6	---	6
7	---	7
8	---	8
9	---	9
10	---	10
11	---	11
12	---	12
13	---	13
14	---	14
15	---	15
16	---	16
17	---	17
18	---	18
19	---	19
20	---	20
21	1	---
22	2	---
23	3	---
24	4	---
25	5	---
26	6	---
27	7	---
28	8	---
29	9	---
30	10	---
31	11	---
32	12	---
33	13	---
34	14	---
35	15	---
36	16	---
37	17	---
38	18	---
39	19	---
40	20	---

(10) Cables with Connectors (1:2)
(32 I/O points)


XW2Z-RI□-□-D1

CN1	CN2	CN3
1	---	3
2	---	4
3	---	1
4	---	2
5	---	5
6	---	6
7	---	7
8	---	8
9	---	9
10	---	10
11	---	11
12	---	12
13	---	13
14	---	14
15	---	15
16	---	16
17	---	17
18	---	18
19	---	19
20	---	20
21	3	---
22	4	---
23	1	---
24	2	---
25	5	---
26	6	---
27	7	---
28	8	---
29	9	---
30	10	---
31	11	---
32	12	---
33	13	---
34	14	---
35	15	---
36	16	---
37	17	---
38	18	---
39	19	---
40	20	---

(11) Cables with Connectors (1:2)
(32 I/O points)


XW2Z-RI□-□-D2

CN1	CN2	CN3
1	---	1
2	---	2
3	---	3
4	---	4
5	---	5
6	---	6
7	---	7
8	---	8
9	---	9
10	---	10
11	---	11
12	---	12
13	---	13
14	---	14
15	---	15
16	---	16
17	---	17
18	---	18
19	---	19
20	---	20
21	1	---
22	2	---
23	3	---
24	4	---
25	5	---
26	6	---
27	7	---
28	8	---
29	9	---
30	10	---
31	11	---
32	12	---
33	13	---
34	14	---
35	15	---
36	16	---
37	17	---
38	18	---
39	19	---
40	20	---



* For the XW2Z-RI/O□-□-D□

Connector Pin Diagram
(from Connector Mating Side)



Item	Part	
Terminal Connector	A side	XG4M-4030-T (MIL connector)
	B side	XG4M-2030-T×2 (MIL connector)
Cable	UL2464 BC20P-SB AWG28(7/0.127)	
	Interface cable	
	Cable color: Gray Tube color: XW2Z-RO□-□-D1 CN2, CN3: Yellow XW2Z-RI□-□-D1/D2 CN2, CN3: Red	

For MIL connectors

(12) Cables with Connectors (1:2)

(16 input points/16 output points)

XW2Z-RM□-□-D1


CN1	CN2	CN3
1	---	1
2	---	2
3	---	3
4	---	4
5	---	5
6	---	6
7	---	7
8	---	8
9	---	9
10	---	10
11	---	11
12	---	12
13	---	13
14	---	14
15	---	15
16	---	16
17	---	17
18	---	18
19	---	19
20	---	20
21	3	---
22	4	---
23	1	---
24	2	---
25	5	---
26	6	---
27	7	---
28	8	---
29	9	---
30	10	---
31	11	---
32	12	---
33	13	---
34	14	---
35	15	---
36	16	---
37	17	---
38	18	---
39	19	---
40	20	---

(13) Cables with Connectors (1:2)


(16 input points/16 output points)

XW2Z-RM□-□-D2

CN1	CN2	CN3
1	---	1
2	---	2
3	---	3
4	---	4
5	---	5
6	---	6
7	---	7
8	---	8
9	---	9
10	---	10
11	---	11
12	---	12
13	---	13
14	---	14
15	---	15
16	---	16
17	---	17
18	---	18
19	---	19
20	---	20
21	1	---
22	2	---
23	3	---
24	4	---
25	5	---
26	6	---
27	7	---
28	8	---
29	9	---
30	10	---
31	11	---
32	12	---
33	13	---
34	14	---
35	15	---
36	16	---
37	17	---
38	18	---
39	19	---
40	20	---



Connector Pin Diagram
(from Connector Mating Side)



Item	Part	
Terminal Connector	A side	XG4M-4030-T (MIL connector)
	B side	XG4M-2030-Tx2 (MIL connector)
Cable	UL2464 BC20P-SB AWG28(7/0.127)	
	Interface cable	
	Cable color: Gray	
	Tube color: XW2Z-RM□-□-D1 CN2: Red, CN3: Yellow XW2Z-RM□-□-D2 CN2: Yellow, CN3: Red	

For Mitsubishi Electric PLCs


(14) Mitsubishi Electric PLC Connecting Cables

(1:2) (32 input points)


XW2Z-RI□C-MN

CN1	CN2	CN3
1A	NC	
1B	3	---
2A	NC	
2B	---	4
3A	NC	
3B		
4A		
4B		
5A	---	5
5B	5	---
6A	---	7
6B	7	---
7A	---	9
7B	9	---
8A	---	11
8B	11	---
9A	---	13
9B	13	---
10A	---	15
10B	15	---
11A	---	17
11B	17	---
12A	---	19
12B	19	---
13A	---	6
13B	6	---
14A	---	8
14B	8	---
15A	---	10
15B	10	---
16A	---	12
16B	12	---
17A	---	14
17B	14	---
18A	---	16
18B	16	---
19A	---	18
19B	18	---
20A	---	20
20B	20	---

Note: The G70V or G7TC connector pin numbers are not the same as the XW2Z-R Cable connector pin numbers. Refer to the datasheet for specific products for details.



Connector Pin Diagram
(from Connector Mating Side)



(15) Mitsubishi Electric PLC Connecting Cables

(1:2) (32 output points)

XW2Z-RO□C-MN

CN1	CN2	CN3
1A	---	4
1B	---	2
2A	4	---
2B	2	---
3A	NC	
3B		
4A		
4B		
5A	---	5
5B	5	---
6A	---	7
6B	7	---
7A	---	9
7B	9	---
8A	---	11
8B	11	---
9A	---	13
9B	13	---
10A	---	15
10B	15	---
11A	---	17
11B	17	---
12A	---	19
12B	19	---
13A	---	6
13B	6	---
14A	---	8
14B	8	---
15A	---	10
15B	10	---
16A	---	12
16B	12	---
17A	---	14
17B	14	---
18A	---	16
18B	16	---
19A	---	18
19B	18	---
20A	---	20
20B	20	---

Note: The G70V or G7TC connector pin numbers are not the same as the XW2Z-R Cable connector pin numbers. Refer to the datasheet for specific products for details.

Item	Part	
Terminal Connector	A side	FCN-367J040-AU/FW*
	B side	XG4M-2030-Tx2 (MIL connector)
Cable	UL2464 BC20P-SB AWG28(7/0.127)	
	Interface cable	
	Cable color: Gray Tube color: XW2Z-RI□C-MN CN2, CN3: Gray XW2Z-RO□C-MN CN2, CN3: Black	

* The connector is made by Fujitsu Component Ltd.

Ratings and Specifications

Rated current	1 A
Rated voltage	250 V
Contact resistance	20 mΩ max. (at 20 mV, 100 mA max.) *
Insulation resistance	1,000 MΩ min. (at 500 VDC) *
Dielectric strength	500 VAC for 1 min (leakage current: 1 mA max.)
Ambient operating temperature	0 to 80°C

* These values are for the connectors.

Safety Precautions

Be sure to read *Safety Precautions for All I/O Relay Terminals* in the website at:

<http://www.ia.omron.com/>.

Warning Indications

Precautions for Correct Use	Supplementary comments on what to do or avoid doing, to prevent failure to operate, malfunction, or undesirable effects on product performance.
------------------------------------	---

Precautions for Correct Use

Wiring

- Do not perform wiring work, remove connectors, or connect connectors while power is being supplied. Electric shock or damage to the device may result.
- Double-check all wiring before turning ON the power supply.
- After wiring, route the cable so that force is not applied directly to the connections.

Bending Radius of Connecting Cables

- To prevent damaging the Connecting Cables, use the following minimum bending radii as guidelines.

Minimum bending radius

Wiring diagram No.	Model	Minimum bending radius (mm)
(1)	XW2Z-RY□C	68
(2)	XW2Z-RA□C	50
(3)	XW2Z-R□C	68
(4)	XW2Z-RI□C-□	88
(5)	XW2Z-RO□C-□	
(6)	XW2Z-R□C-□-□	99
(7)	XW2Z-RO□C	68
(8)	XW2Z-RI□C	
(9)	XW2Z-RO□-□-D1	88
(10)	XW2Z-RI□-□-D1	
(11)	XW2Z-RI□-□-D2	
(12)	XW2Z-RM□-□-D1	
(13)	XW2Z-RM□-□-D2	
(14)	XW2Z-RI□C-□-MN	
(15)	XW2Z-RO□C-□-MN	

Refer to the manuals for the connected PLC for the connections to I/O Units for OMRON PLCs.

Series	Model	Man. No.	Manual Name
CS1	CS1G-CPU□□H, CS1H-CPU□□H	W339	Programmable Controllers Operation Manual
CJ1	CJ1H-CPU□□H-R, CJ1G/H-CPU□□H, CJ1G-CPU□□P, CJ1M-CPU□□, CJ1G-CPU□□	W393	CJ Series Programmable Controllers Operation Manual
CJ2	CJ2H-CPU6□-EIP, CJ2H-CPU6□, CJ2M-CPU□□	W472	CJ-series CJ2 CPU Unit Hardware User's Manual
NJ	NJ501-□□□□	W500	NJ-series CPU Unit Hardware User's Manual
NX	NX-ID□□□□, NX-IA□□□□, NX-OD□□□□, NX-OC□□□□, NX-MD□□□□	W521	NX-series Digital I/O Units User's Manual

[illegible]

Terms and Conditions Agreement

Read and understand this catalog.

Please read and understand this catalog before purchasing the products. Please consult your OMRON representative if you have any questions or comments.

Warranties.

- (a) Exclusive Warranty. Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.
- (b) Limitations. OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right. (c) Buyer Remedy. Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See <http://www.omron.com/global/> or contact your Omron representative for published information.

Limitation on Liability; Etc.

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Suitability of Use.

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products.

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Performance Data.

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

Change in Specifications.

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions.

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

OMRON AUTOMATION AMERICAS HEADQUARTERS • Chicago, IL USA • 847.843.7900 • 800.556.6766 • www.omron247.com

OMRON CANADA, INC. • HEAD OFFICE

Toronto, ON, Canada • 416.286.6465 • 866.986.6766 • www.omron247.com

OMRON ELECTRONICS DE MEXICO • HEAD OFFICE

México DF • 52.55.59.01.43.00 • 01-800-226-6766 • mela@omron.com

OMRON ELECTRONICS DE MEXICO • SALES OFFICE

Apodaca, N.L. • 52.81.11.56.99.20 • 01-800-226-6766 • mela@omron.com

OMRON ELETRÔNICA DO BRASIL LTDA • HEAD OFFICE

São Paulo, SP, Brasil • 55.11.2101.6300 • www.omron.com.br

OMRON ARGENTINA • SALES OFFICE

Cono Sur • 54.11.4783.5300

OMRON CHILE • SALES OFFICE

Santiago • 56.9.9917.3920

OTHER OMRON LATIN AMERICA SALES

54.11.4783.5300

OMRON EUROPE B.V. • Wegalaan 67-69, NL-2132 JD, Hoofddorp, The Netherlands. • +31 (0) 23 568 13 00 • www.industrial.omron.eu

Authorized Distributor:

Controllers & I/O

- Machine Automation Controllers (MAC) • Motion Controllers
- Programmable Logic Controllers (PLC) • Temperature Controllers • Remote I/O

Robotics

- Industrial Robots • Mobile Robots

Operator Interfaces

- Human Machine Interface (HMI)

Motion & Drives

- Machine Automation Controllers (MAC) • Motion Controllers • Servo Systems
- Frequency Inverters

Vision, Measurement & Identification

- Vision Sensors & Systems • Measurement Sensors • Auto Identification Systems

Sensing

- Photoelectric Sensors • Fiber-Optic Sensors • Proximity Sensors
- Rotary Encoders • Ultrasonic Sensors

Safety

- Safety Light Curtains • Safety Laser Scanners • Programmable Safety Systems
- Safety Mats and Edges • Safety Door Switches • Emergency Stop Devices
- Safety Switches & Operator Controls • Safety Monitoring/Force-guided Relays

Control Components

- Power Supplies • Timers • Counters • Programmable Relays
- Digital Panel Meters • Monitoring Products

Switches & Relays

- Limit Switches • Pushbutton Switches • Electromechanical Relays
- Solid State Relays

Software

- Programming & Configuration • Runtime