



## M39012/05-0101

### Configuration

- N Male Connector
- 50 Ohms

#### **Features**

- · Max. Operating Frequency 11 GHz
- Excellent VSWR of 1.25:1

### **Applications**

· General Purpose Test

- · Right Angle Body Geometry
- · Connector Interface Types: RG214
- · Gold Plated Beryllium Copper Contact
- QPL Part
- Custom Cable Assemblies

#### **Description**

Pasternack's M39012/05-0101 N male connector is part of our full line of RF components available for same-day shipping. Our type N male connector operates up to a maximum frequency of 11 GHz and offers excellent VSWR of 1.25:1. Its right angle body geometry allows for easier connections in tight spaces.

Our type N male right angle connector M39012/05-0101 datasheet specifications and drawing with dimensions are shown below in this PDF. Pasternack's broad catalog of RF, microwave and millimeter wave connectors allows designers to configure and customize their signal connections however they like. Whether the need is to provide an I/O for a board design, or simply create a custom cable assembly configuration, Pasternack has the right connector for the job. Pasternack can also expertly build your custom cable assemblies for you and ship same-day.

### **Electrical Specifications**

Description	Minimum	Typical	Maximum	Units
Frequency Range	DC		11	GHz
VSWR			1.25:1	
Dielectric Withstanding Voltage (AC)			2,500	Vrms
Impedance		50		Ohms

## **Mechanical Specifications**

Size

 Length
 1.66 in [42.16 mm]

 Width
 1.36 in [34.54 mm]

 Height
 0.79 in [20.07 mm]

 Weight
 0.78 lbs [353.8 g]

#### **Material Specifications**

Description	Material	Plating
Contact	Beryllium Copper	Gold
Insulation	PTFE	
Outer Conductor	Brass	Silver
Body	Brass	Silver





# M39012/05-0101

**Environmental Specifications Temperature** 

Compliance Certifications (see product page for current document)

**Plotted and Other Data** 


Notes:






## M39012/05-0101


### **Assembly Instruction**




1) Trim cable jacket to dimension A. Slide backnut, washer, V-gasket, and braid clamp onto cable as shown. Cable jacket should bottom on step in braid clamp.



2) Comb braid wires out straight an fold back over front shoulder of braid clamp (braid wires should not overlap one another after folding). Trim braid wires flush with step of braid clamp. Trim cable dielectric and center conductor to dimensions B and C.



3) If support insulator is provided for RG-62 or 71 cable, insert into hollow in dielectric. Assemble rear bushing or washer (if supplied), rear insulator (if captive contact) and contact, and solder contact to center conductor. Rear of contact should be flush with cable dielectric end. For right angle connectors with access cap, omit this step entirely.



4) Insert prepared cable and hardware into body and tighten backnut. For right angle connectors with access cap, solder center conductor into slot in contact and tighten access cap.





## M39012/05-0101

N Male Right Angle Connector Clamp Attachment for RG214 from Pasternack Enterprises has same day shipment for domestic and International orders. Our RF, microwave and millimeter wave products maintain a 99.4% availability and are part of the broadest selection in the industry.

Click the following link (or enter part number in "SEARCH" on website) to obtain additional part information including price, inventory and certifications: N Male Right Angle Connector Clamp Attachment for RG214 M39012/05-0101

URL: https://www.pasternack.com/n-male-rg214-connector-m39012-05-0101-p.aspx

The information contained within this document is accurate to the best of our knowledge and representative of the part described herein. It may be necessary to make modifications to the part and/or the documentation of the part in order to impliment improvements. Pasternack Enterprises reserves the right to make such changes as required. Unless otherwise stated, all specifications are nominal. Pasternack Enterprises does not make any representation or warranty regarding the suitability of the part described herein for any particular purpose, and Pasternack Enterprises does not assume liability arising out of the use of any part or document.

